

# Worksurface Mounting Instructions: 2-Leg Equal Corners 40"- 42" W × 23"- 24" D, T404023

## 1 Attach Base to Worksurface

### If you have a Workrite Pre-Drilled Worksurface:



**Note: Avoid trip or tip hazards!**  
For uniquely shaped, non-rectangular worksurfaces, it is the installer's responsibility to position the worksurface to minimize extended overhangs and position feet fully under the worksurface.

- a** Position leg assemblies to align mounting holes in brackets to pre-drilled holes in worksurface as shown below. Attach using #12 × 3/4" Pan Head Laminate Top Screws included with your frame set. Continue to follow the frame set instructions to complete workcenter assembly.

### If you have a non-Workrite Worksurface:

- a** Position Frame Set as shown, centered left to right.
- b** Make sure feet do not exceed rear edge.

Note suggested placement of Control Box, Cable Spools and Switch. Continue to follow the frame set instructions to complete workcenter assembly.

