

# Worksurface Mounting Instructions: 2-Leg Offset Corner 40"– 42" W × 58"– 60" W × 23"– 24" D, T405823

## 1 Attach Base to Worksurface

**If you have a Workrite Pre-Drilled Worksurface:**

- a** Position leg assemblies to align mounting holes in brackets to pre-drilled holes in worksurface as shown below. Attach using #12 × 3/4" Pan Head Laminate Top Screws included with your frame set. Continue to follow the frame set instructions to complete workcenter assembly.

**If you have a non-Workrite Worksurface:**

- a** Position Frame Set as shown.
- b** Make sure feet do not exceed rear edge.

Note suggested placement of Control Box, Cable Spools and Switch. Continue to follow the frame set instructions to complete workcenter assembly.



**Note: Avoid trip or tip hazards!**  
For uniquely shaped, non-rectangular worksurfaces, it is the installer's responsibility to position the worksurface to minimize extended overhangs and position feet fully under the worksurface.

